




Mountain fold on each of the dotted lines.

Mountain fold on each of the dotted lines.


Mountain fold on each of the dotted lines.

Mountain fold on each of the dotted lines.

Mountain fold on each of the dotted lines.




Tape the legs of the LED to the copper tape strips. Remember, the long leg is positive.
Tape the battery to keep it in place.
Tuck the front house flap over the top of the battery. Secure with paperclips.




Continue this tape onto the other side of the card.

Tape the legs of the LED to the copper tape strips. Remember, the long leg is positive.
Tape the battery to keep it in place.
Tuck the front house flap over the top of the battery. Secure with paperclips.




Continue this tape onto the other side of the card.

Tape the legs of the LED to the copper tape strips. Remember, the long leg is positive.
Tape the battery to keep it in place.
Tuck the front house flap over the top of the battery. Secure with paperclips.




Continue this tape onto the other side of the card.

Tape the legs of the LED to the copper tape strips. Remember, the long leg is positive.
Tape the battery to keep it in place.
Tuck the front house flap over the top of the battery. Secure with paperclips.



Continue this tape onto the other side of the card.

Tape the legs of the LED to the copper tape strips. Remember, the long leg is positive.
Tape the battery to keep it in place.
Tuck the front house flap over the top of the battery. Secure with paperclips.



Continue this tape onto the other side of the card.